


IGNIJET 12_1CH_v312 KTM


Front view of the ECU connector

Main connector



F part SWS 6189-710 6
Term part SWS 8240-0245

Optional connector



F part SWS 6180-677 1
Term part SWS 1500-0406
Seal part SWS 7106-82234

černý konektor

pin nr.	function	pin nr.	function	pin nr.	
1	+12V Supply	12	+5V REF	23	GND
2	POUT_3	13	diag. CAN+	24	Pickup input
3	POUT_1	14	diag. CAN-	25	
4	OUT INJ1	15	TPS Input	26	K-Line
5	POUT_2	16	MIN_7	27	IAP Input
6	GND	17	GND	28	MIN_5
7	POUT_5	18	MIN_2	29	MIN_4
8	POUT_6	19	ATS input	30	MIN_6
9	MP_POUT_4 (MIN/POUT)	20	Lambda input	31	MIN_3
10	POUT_7	21	TWS input	32	MIN_1
11	IC Out for ignition coil	22	GND	33	GND
a	W/Or Speed 1 (front) IN	b		c	Bl/W POUT_1
d	P Speed (rear) IN	e	Lbl GND	f	Gy/Bk AP Input