Open box - connection manual for motorcycle
MZ125

Connection

There leads 2 wires from speedometer sensor to sealed connector at ignition unit (both black, see picture below). Disconnect this connector and insert appropriate connector from Open box to this point (direction to ignition unit). Orange wire from OpenBox should be connected to position marked "SPEED".
Red wire from Open box connect using red wire to +12 V. (white/red at ignition unit).



Producer: **IgniTech**
Ceskobratrska 84
535 01 PRELOUC
ignitech@ignitech.cz
www.ignitech.cz